










<div> USER'S MANUAL Watches with multifunction movement ISA SWISS 8516</div> <div>www.vostok-europe.com</div>			
CONTENT OF THE BOOKLET		FUNCTIONS	
Functions 03 Main 04 Synchronizing the hands 05 Time setting 06 Alarm mode 07 Time 2 mode 08 Chrono mode 09 Date mode 10		Analogical display: <ul style="list-style-type: none">• Hands and minutes synchronized with the digital display.• Seconds indication on subdial. Digital display: <ul style="list-style-type: none">• Chrono 100 hours (1100 sec. the 1st. hour).• Day / Date indication• 100-years perpetual calendar.• Alarm alarm• End of battery life signal.• Visual clearing of the display in setup mode.• 12 / 24 hour mode.• Display illumination by crowns up or down. Caution: TURN THE CROWN SLIGHTLY BUT DON'T ROTATE IT! Fast rotation can cause damage of the movement!	
MAIN		SYNCHRONIZING THE HANDS	
04  Push the crown to change mode		05  Push the crown to exit	
TIME SETTING		ALARM MODE	
06  Push A to set time		07  Push B to set alarm	
TIME 2 MODE		CHRONO MODE	
08  Push A to set time		09  Push B to set time	
DATE MODE		LOW BATTERY	
10  Push A to set date		11  Push B to set date	